



**9V** REQUIRES ONE  
9V BATTERY ①

### STORE WEIGHT INTO MEMORY

1. Press and hold the **ON** button until numbers appear on the display and flash. Scale has now been zeroed.
2. Add fish to be weighed.
3. Press the **MEMORY** button to enter into "memory" mode. The weight of the fish has been saved into short-term memory. Fish can be removed from scale without losing weight.
4. Press the **MEMORY** button to advance through the storage bins (1-8) if a different location is wanted. To view total weight stored in memory, press **MEMORY** button until "Total" screen is displayed.
5. To save weight to selected storage bins, press and hold the **MEMORY** button until memory indicator ② stops blinking.
6. Scale will return to measuring mode automatically and advance to the next storage bin to be ready for the next fish.
7. Press and hold the **ON** button to turn off the scale (around 4 seconds). The scale will turn off automatically if there is no command to the scale after 4 minutes.

### TO REVIEW STORED WEIGHTS

1. Press and hold the **ON** button until numbers appear on the display and flash. Scale has now been zeroed.
2. Press **MEMORY** button to enter memory mode.
3. Once in memory mode, press the **MEMORY** button to advance through the storage bins.
4. Press the **ON** button to return to measure mode. The scale will return to measure mode automatically if there is no command to the scale after 5 seconds.

### TO ZERO OUT THE SCALE

1. Press the **ON** button once.

### TO RESET ALL STORAGE BINS TO ZERO

1. Press the **MEMORY** button to enter into "Memory" mode.
2. Press and hold the **ON** button & **MEMORY** button until **0000** blinks on the display, and then press the **MEMORY** button within 2 seconds.

### TO TURN ON THE BACK LIGHT

1. Press and hold the **ON** button until the back light indicator ③ comes on. (2 seconds)

### TO TURN OFF THE BACK LIGHT

1. Press and hold the **ON** button until the back light indicator turns off. (2 seconds)

### TO SWITCH THE UNITS (LB OZ/LB/KG)

1. Once in "Measure" mode, press and hold the **MEMORY** button until **LB OZ**, **LB** and **KG** appear on the display circularly, and then loosen the button to choose the unit that you wanted.